

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WHEN USING A KEYBOARD:

- Maintain proper posture and avoid excessive force on the keys.
- Take regular breaks to prevent hand fatigue.
- Clean the keyboard regularly to remove dust and dirt.
- Avoid exposing the keyboard to liquids.
- Keep the keyboard in a suitable environment, free from extreme temperatures or humidity.

Remember these tips for a comfortable and durable keyboard experience.

WARRANTY

12 MONTHS


WARRANTY

GUARANTEE


Non-human damage
12-month warranty

产品基础


PRODUCT BASIC INFORMATION




说明书
Manual




接轴拔键器
Switch and Keycaps Puller



键盘
Keyboard



Type-C 数据线
Type-C Cable




2.4G接收器
2.4G Receiver

指示灯


INDICATOR LIGHT

K68Pro



Caps Lock

Win Lock




Win Lock


充电指示: 充电时呼吸状态、充满常亮、低电压闪烁

Charging indicator: Breath mode during charging, steady light when fully charged, and low voltage blinking.

K20



Num



充电指示: 充电时常亮、充满熄灭低电压时闪烁

Charging indicator: Solid light during charging, off when fully charged, and flashing when battery is low

尺寸/Size		Layout	版本/Version	背光/Backlit	轴体/Key Switches
K68PRO	329.4(L)×118.15(W)×37.9(H)±2	67 keys	有线/2.4G/BT USB-C wired/2.4G wireless/BT	RGB	机械轴体 Mechanical switches
K20	89.7(L)×132.5(W)×38.3(H)±2	19 keys			

有线模式
WIRED MODE

K68Pro

1. 连接USB至设备，旋钮拨到OFF为有线模式
Connect the USB to the device and turn the knob to "OFF" for wired mode.
(Note: Wired mode can only be used when the knob in the upper right corner is turned to "OFF".)

2. (建议: 使用5V 1A额定电源为键盘充电)
(Recommended: Use a 5V 1A power supply for keyboard charging).

K20

1. 有线模式: 连接USB至设备，开关拨到中间为有线模式
Connect the USB cable to the device and set the switch to the middle position for wired mode.

BT连接
BT CONNECTION

K68Pro

1. 拨动开关到BT1、BT2、BT3位置
Toggle switch to BT1、BT2、BT3 for BT Mode.

2. 长按Fn+Q/W/E进入配对模式
Press and hold Fn+Q/W/E to pair with new BT devices

K20

1. 开关拨到B状态
Setting the switch to the "B" position

2. 短按Fn+1/2/3至BT频道
Short press Fn+1/2/3 to BT channel

长按Fn+1/2/3进入配对模式
Long press Fn+1/2/3 to enter pairing mode

2.4G连接
2.4G RECEIVER CONNECTION

K68Pro


1. 旋钮开关拨到2.4G位置。
2. FN+P长按对码，P键内灯插入接收器，P键停止闪烁即对码成功。
1.Switch to the 2.4G position,
2.Press and hold FN+P to pair,
As the P key flashing, plug the receiver into the device.
if the P key stops flashing, pairing is successful.


K20


1. 开关拨到G状态。
2. FN+0长按对码，0键快闪插入接收器，0键停止闪烁即对码成功。
1. Switch to the "G" position.To pair the receiver,
2. long-press FN + 0. The 0 key will flash. Insert the receiver and wait for the flashing to stop, indicating successful pairing.


背光控制
BACKLIGHT CONTROL


K68Pro


Fn +  支持多种背光效果切换
Multiple backlight effects switch


Fn +  背光单色切换
Backlight monochrome switching


Fn +  背光亮度+
Backlight brightness +

Fn +  背光亮度-
Backlight brightness -


Fn +  背光速度 -
Backlight speed -


Fn +  背光速度+
Backlight speed +


Fn +  窗口锁定
Windows lock


Fn +  长按3秒，恢复出厂设置
Long-press for three seconds to restore factory settings


K20



Fn +  多种动态背光模式切换
Switch between multiple dynamic backlight modes

Fn +  背光颜色切换
Switch backlight colors

Fn +  背光亮度增加
Backlight brightness +

Fn +  背光亮度减小
Backlight brightness -

Fn +  长按3秒，恢复出厂设置
Long-press for three seconds to restore factory settings



ISED STATEMENT:

English: This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device must not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-3(B).
French: Cet appareil contient des émetteur(s)/récepteur(s) exempt(s) de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences.
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

l'appareil numérique du clem conforme canadien peut -3 (b) / nmb -3 (b).
This device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and complies with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance: cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 2.5 du crr -102 et conforme avec les 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.
This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

BATTERIES:

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the light.


- 1) Replacement of a battery with an incorrect type that can defeat a safeguard;
- 2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
- 3) Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- 4) A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.



GUARANTEE
Non-human damage
12-month warranty


FN组合功能键 K68Pro

FN KEY



特殊功能键 K68Pro


SPECIAL FUNCTION KEYS



电池电量提示

KEYBOARD BATTERY LEVEL INDICATION AND CHECK

K68Pro



按FN+ENTER 查看电池电量情况
Pressing FN+ENTER allows you to view the battery level status.Each key from "1" to "0" represents a specific battery level range.

比如:
For example:

11 背光亮 表示此时键盘10%的电量
The backlight of the "1" key is illuminated, indicating that the keyboard's current battery level is at 10%.

11 ~ 00 背光同时亮, 表示此时键盘20%的电量
The "1" and "2" keys are both illuminated, indicating that the keyboard's current battery level is at 20%.

以此类推
Similarly

11 ~ 01 背光同时亮, 表示此时键盘电量 100%
When both the "1" and "0" keys are illuminated, it signifies that the keyboard's battery level is at 100%.

K20



长按旋钮三秒切换旋钮三种模式
Long-press the knob for three seconds to switch between three modes.


1. 音量模式 (默认): 顺时针音量 +, 逆时针音量 -, 按压静音 (旋转时旋钮亮红色)
1.Volume mode (default): Rotating the knob clockwise increases the volume, rotating it counterclockwise decreases the volume, and pressing the knob mutes the sound (the knob lights up red while rotating).
2. 背光模式: 顺时针背光亮度 +, 逆时针背光亮度 -, 按压切换灯效 (旋转时旋钮亮绿色)
2.Backlight mode: Clockwise rotation increases brightness, counterclockwise rotation decreases brightness, and pressing the knob toggles between lighting effects (knob lights up green while rotating).
3. 鼠标滚轮模式: 顺时针向下翻页, 逆时针向上翻页 (旋转时旋钮亮蓝色)
3.Mouse scroll wheel mode: Rotating the knob clockwise scrolls down, rotating it counterclockwise scrolls up (the knob lights up blue while rotating).

WINDOWS多媒体键 K68Pro

WINDOWS MULTIMEDIA KEYS

Windows系统 (FN+A: 切换到Windows系统)
In Windows mode (FN+A: Switch to Windows system, FN+S: Switch to macOS system)

FN + 左 Ctrl (主键功能和复合键的第二功能互换)
(FN + Left Ctrl: Swap primary key function and secondary function of compound keys.)



MAC多媒体键 K68Pro

MAC MULTIMEDIA KEYS

MAC系统 (FN+s: 切换到MAC系统)
In macOS mode (FN+S: Switch to macOS system; FN+A: Switch to Windows system)

(FN + 左 Ctrl (主键功能和复合键的第二功能互换)
(FN + Left Ctrl: Swap primary key function and secondary function of compound keys)



Thank you for choosing KZZI products! If you have any questions or need assistance, please feel free to contact us. Our team is dedicated to providing support and addressing your inquiries.

We highly value your feedback and suggestions as they help us continuously improve and enhance product quality. Once again, we appreciate your support for KZZI!